

EF3003, SF3003, DF3003

REPLACEMENT PARTS

FIREPLACE 30"

CATALOGUE NO.

EF3003, SF3003, DF3003

PART NO.

6901110259, 6901110359, 6901110459

MOD LEVEL:

A

MADE IN:

CHINA

REPLACEMENT PART

REPLACEMENT PART NO.

1. LOG SET	0438550100RP
2. GRILLE	1009070159RP
3. HEATER ASSEMBLY	2200490201RP
4. LOWER LIGHT HARNESS	2500190500RP
5. UPPER LAMPHOLDER ASSEMBLY	4200120900RP
6. HEATER ON/OFF SWITCH	2800070200RP
7. CIRCUIT BOARD	3000210100RP
8. LED/SWITCH HARNESS	3000210400RP
9. REMOTE CONTROL	3000211600RP-ELECTRAFLAME
10. REMOTE CONTROL	3000211500RP-SYMPHONY
11. REMOTE CONTROL	3000211300RP-DIMPLEX
12. FLAME SPEED CONTROL	3000240100RP
13. FLAME MOTOR	3000240200KIT
14. BUSHING, SNAP-IN	8500000400RP
15. DIMMER CONTROL	3000250100RP
16. CORD SET	4100040500RP
17. REFLECTOR ASSEMBLY	5900080700RP
18. GLASS, SEMI-SILVERED	5900300200RP
19. FRONT GLASS	5900310200RP
20. CONTROL KNOB	8800000200RP
21. FOOT FIREPLACE	8800100100RP
22. DECAL, SIDE BRICK	7108890200RP
23. CUTOUT	2300270300RP

EF3003, SF3003, DF3003

REPLACEMENT PARTS

FIREPLACE 30"

CATALOGUE NO.	EF3003, SF3003, DF3003
PART NO.	6901110259, 6901110359, 6901110459
MOD LEVEL:	NONE
MADE IN:	CHINA

REPLACEMENT PART	REPLACEMENT PART NO.
1. LOG SET	0438550100RP
2. GRILLE	1009070159RP
3. HEATER ASSEMBLY	2200490200RP
4. LOWER LIGHT HARNESS	N/A
5. UPPER LAMPHOLDER ASSEMBLY	4200120900RP
6. HEATER ON/OFF SWITCH	2800070200RP
7. CIRCUIT BOARD	3000210100RP
8. LED/SWITCH HARNESS	3000210400RP
9. REMOTE CONTROL	3000211600RP-ELECTRAFLAME
10. REMOTE CONTROL	3000211500RP-SYMPHONY
11. REMOTE CONTROL	3000211300RP-DIMPLEX
12. FLAME SPEED CONTROL	3000240100RP
13. FLAME MOTOR	3000240200KIT
14. BUSHING, SNAP-IN	8500000400RP
15. DIMMER CONTROL	3000250100RP
16. CORD SET	4100040500RP
17. REFLECTOR ASSEMBLY	5900080700RP
18. GLASS, SEMI-SILVERED	5900300200RP
19. FRONT GLASS	5900310200RP
20. CONTROL KNOB	8800000200RP
21. FOOT FIREPLACE	8800100100RP
22. DECAL, SIDE BRICK	7108890200RP

EF3003

REPLACEMENT PARTS

FIREPLACE 30"

CATALOGUE NO.	EF3003
PART NO.	6901110159
MOD LEVEL:	NONE
MADE IN:	CANADA

REPLACEMENT PART	REPLACEMENT PART NO.
1. LOG SET	0438550100RP
2. GRILLE	1009070159RP
3. HEATER ASSEMBLY	2000170300RP
4. LOWER LIGHT HARNESS	2500190100RP
5. UPPER LAMPHOLDER ASSEMBLY	2500080100RP
6. HEATER ON/OFF SWITCH	2800070200RP
7. CIRCUIT BOARD	3000210100RP
8. LED/SWITCH HARNESS	3000210400RP
9. REMOTE CONTROL	3000211600RP-ELECTRAFLAME
10. REMOTE CONTROL	3000211500RP-SYMPHONY
11. REMOTE CONTROL	3000211300RP-DIMPLEX
12. FLAME SPEED CONTROL	3000180300RP
13. FLAME MOTOR	2000150200RP
14. BUSHING, SNAP-IN	8500000600RP
15. DIMMER CONTROL	2800020100RP
16. CORD SET	4100040400RP
17. REFLECTOR ASSEMBLY	5900080700RP
18. GLASS, SEMI-SILVERED	5900300200RP
19. FRONT GLASS	5900310200RP
20. CONTROL KNOB	8800000800RP
21. FOOT FIREPLACE	8800100100RP
22. DECAL, SIDE BRICK	7108890200RP
23. FLAME PANEL	5900320100RP

WIRING DIAGRAM

